

## Instructions for applying TWINSCREEN FLEX with water

1. Prepare the surface on which you are going to place the TWINSCREEN FLEX (glass, TWINSCREEN SOLID screens, pre-cut to size, or window)

You will need:

- A spray, filled with soapy water
- A rubber scraper for smoothing out bubbles
- A cloth

2. Clean and dry the surface carefully

3. Spray water on the final surface

4. Carefully position the TWINSCREEN FLEX by pressing down with the rubber scraper from the centre to the outer edges, to make sure you iron out every last bubble

5. Check that there are no bubbles remaining between the TWINSCREEN FLEX and the application surface, and smooth out as necessary

6. It's finished

### Contact TWINSCREEN

by telephone  
+33 6 67 52 12 43

by fax  
+33 9 72 13 20 98

by post  
87 allée ds goelands  
34280 La Gde Motte - France